


Trusted solutions for common toilet problems.

Get the basics on how your toilet works:

- When you flush, a lift chain or wire raises the tank ball or flapper from the valve seat.
- Gravity causes water to flow from the tank into the bowl, then out the drain.
- As the tank's water level drops, the float and float rod drop as well, opening the fill valve and allowing water back into the tank through the refill tube.
- The float rod turns off the fill valve once the tank is filled to the correct level.



Need more help?

Visit www.plumbcraft.com for online how-to videos and other resources.

PlumbCraft® has been the trusted brand for plumbing home repair products for more than 50 years. Whether you're a seasoned plumber or a casual do-it-yourselfer, PlumbCraft® makes any plumbing repair job much easier.

PlumbCraft® is the trusted brand of choice for plumbing repair made easy throughout the entire home.

PlumbCraft® Essential Take-Home Guides are available for each of these plumbing home repair projects:

CONNECTION REPAIR

TOILET REPAIR

WATER SUPPLY REPAIR

DRAIN REPAIR

HOSE & PIPE REPAIR

SINK & FAUCET REPAIR

Need more help?

Visit www.plumbcraft.com for online how-to videos and other resources.

PlumbCraft®

PlumbCraft® is a registered trademark of Waxman Consumer Products Group, Inc.
Bedford Heights, OH 44146
www.plumbcraft.com
©2016 Waxman. All rights reserved.

PlumbCraft®

TOILET REPAIR SOLUTIONS

Your Essential Take-Home Guide

Simplify your repair project:

- Check product codes to quickly find parts
- Take home this detailed guide to help with the repair
- Watch online how-to videos at plumbcraft.com



PlumbCraft® Toilet Repair Solutions

DETERMINE THE PROBLEM	DISCOVER THE CAUSE	FIND YOUR SOLUTION
Toilet keeps running	<ul style="list-style-type: none"> Old/worn flapper Pitted flush valve seat Leaky float ball Old/worn fill valve 	T-4 or T-10 T-2 T-18 or T-7 T-1
Toilet won't flush	<ul style="list-style-type: none"> Corroded flush lever Damaged lift chain Damaged lift wires 	T-8 T-4 T-6
Toilet wobbles at floor	<ul style="list-style-type: none"> Corroded/stripped toilet bolts Depressed/dry wax ring 	T-13 T-17
Water leaks from under the tank	<ul style="list-style-type: none"> Cracked/dry tank to bowl washer 	T-12 T-11 T-2
Water leaks from supply tube	<ul style="list-style-type: none"> Worn supply nut Dry/cracked washer Cracked supply tube 	WS-8* WS-2*
Toilet won't completely flush	<ul style="list-style-type: none"> Damaged/leaky overflow tube 	T-5 and T-9
Toilet bowl is clogged	<ul style="list-style-type: none"> Blocked drain 	Unclog with toilet auger
Seat is loose or wobbly	<ul style="list-style-type: none"> Damaged seat hinge or bumpers 	T-3 and T-16 ←

*Find these products in Water Supply Repair.

PlumbCraft® products are packaged and marked to help you find plumbing repair parts quickly. Just use the chart to name your problem, determine the cause and find your solution. Then, look for the part codes on every package to easily find what you need.

Tip: Before beginning any repairs, always shut off your water at the Water Supply Valve.

Before You Start

Be sure to look for cracks in the ceramic of your toilet – by checking for potential leaks in the bowl and tank, you can avoid unnecessary repairs.



Installation

Find detailed directions for complete installation on the back of each product package. Each package also offers information on specific tools you may need, and helpful tips to make your projects easier.

